

👁 Note!

Please note that there can be small differences between your product and the images in these instructions.

👁 Note!

Please note that during storage and transport, especially at high ambient temperature, some of the oil and grease used for assembly may leak and stain the packaging. This will not cause damage to the product, wipe off the excessive oil or grease with a cloth.

👁 Note!

Before you install this product, check the kit contents. If anything is missing, please contact an Öhlins dealer.

⚠ Warning!

Before you install this product, read the Öhlins Owner's manual. This product is an important part of the vehicle and the vehicle stability.

Cancellation kit, Audi R8 2015-

35020-28

Mounting Instructions

MOUNTING INSTRUCTIONS

⚠ Warning!

We strongly recommend to let an Öhlins dealer install this product.

⚠ Warning!

If you work with a lifted vehicle, make sure that it is safely supported to prevent it from tipping over.


Front axle right

1

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

2

Fix the canceller with supplied cable ties on the vehicle chassis.



MOUNTING INSTRUCTIONS

⚠ Warning!

We strongly recommend to let an Öhlins dealer install this product.

⚠ Warning!

If you work with a lifted vehicle, make sure that it is safely supported to prevent it from tipping over.

Front axle left

1

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

2

Fix the canceller with supplied cable ties on the vehicle chassis.



MOUNTING INSTRUCTIONS



Rear axle right

1

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

2

Mount the canceller with the supplied edge clips on the chassis edge. Fix the cable with cable ties.



MOUNTING INSTRUCTIONS


Rear axle left

1

Run the standard damper control wire to the canceller connector. Insert the connector into the canceller connector until it locks.

2

Mount the canceller with the supplied edge clips on the chassis edge. Fix the cable with cable ties.



Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI_35020-28_0
Issued 2019-06-12

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Racing AB
Box 722
S-194 27 Upplands Väsby, Sweden
Phone +46 8 590 025 00
fax +46 8 590 025 80



www.ohlins.com